



RANCO • PARAGON • CASTFUTURA

Installation Guide

1. Tighten plug into 3/8” pipe thread opening.
2. Place packing nut on bulb and slide nut up capillary.
3. Insert bulb through plug and position as required.
4. Mount 3 slotted washers on capillary, alternating slot direction.
5. Wind graphite packing around capillary.
6. Place remaining 3 slotted washers on capillary in same manner, and tighten packing nut into plug to compress washers and center packing.



RANCO • PARAGON • CASTFUTURA

Customer Service

+1 800 304 6563

HVACCustomerService@robertshaw.com

Technical Service

+1 800 445 8299

TechnicalService@robertshaw.com

www.robertshaw.com

©2024 Robertshaw

10/24 – 1-486 Rev C