

AFTERMARKET RESIDENTIAL LAUNDRY OPPORTUNITIES



Robertshaw



Interactive
Version


Visit our Website >



Robertshaw's quality-tested components are engineered for maximum durability, ensuring your washer and dryer run smoothly for years to come.


WASHER OPPORTUNITIES

Residential top or front load washers



DRYER OPPORTUNITIES

Residential top or front load dryers



BRAKE ACTUATORS



AFV01100-02U

- Functions as a safety device to block the washing machine's drum as per the programmed commands or on opening a vertical washing machine's lid.

[Learn More](#) »

Part No.	Description	Replaces
AFV01100-02U	Brake Actuator for Top Load Washing Machines 127V/60Hz	Whirlpool 326055533
AFV01200-02U	Brake Actuator for Top Load Washing Machines 220V/60Hz	Whirlpool 326055534
AFV02100-02U	Brake Coupling Actuator 127V	Electrolux 64500661
AFV03100-02U	Brake Actuator 110V	Whirlpool W11428263
AFV04100-02U	Brake Actuator 127V	Electrolux 64491711
AFV09100-02U	Brake Actuator for Top Load Washing Machines 127V/60Hz	Electrolux 64484603
AFV09100-03U	Brake Actuator with Steel Cable 127V	Electrolux 64484603
AFV09200-02U	Brake Actuator for Top Load Washing Machines 220V/60Hz	Electrolux 64484604

DRAIN PUMPS



BSM028-01

- Ensures proper water flow, prevents standing water, and supports overall cleaning effectiveness, helping appliances operate smoothly.

[Learn More](#) »

Part No.	Description	Replaces
BSM028-01U	Universal Drain Pump Motor 127V/60HZ (New Model)	N/A
BSM028-02U	Universal Drain Pump Motor 220V/60Hz (New Model)	N/A
BSM028-03U	Universal Drain Pump Motor 220V/50HZ (New Model)	N/A

Part No.	Description	Replaces
BSM028-04	Drain Pump Motor 220V/50Hz plug-in front connector	N/A
BSM028-05	Drain Pump Motor 220V/50Hz plug-in rear connector	N/A
BSM028-80	Universal Drain Pump Motor 220-240V/50Hz 80W	N/A

HOT SURFACE IGNITORS



- The Robertshaw Dryer Ignitor Kits are designed to deliver high-temperature, dependable ignition cycle after cycle and hassle free installation.

[Learn More](#) »

Part No.	Description	Replaces
41-311	Dryer Ignitor	GE WE4X750
41-590	Dryer Ignitor	Whirlpool 4391996

PRESSURE SWITCHES



- Ensures optimal performance and efficiency in washing machines by accurately monitoring and controlling the amount of water used during each cycle.
- Prevents overfilling and under filling, protecting both the appliance and the user while supporting consistent wash results.

[Learn More](#) »

Part No.	Description	Replaces
791-9301	Washer Water Level Pressure Switch	Whirlpool W10231402
791-9401	Washer Water Level Pressure Switch	Whirlpool W10231403
791-9501	Washer Water Level Pressure Switch	Whirlpool W10231400

Part No.	Description	Replaces
791-9632-AM	Washer Water Level Pressure Switch	Speed Queen 202937
792-9404-AM	Washer Water Level Pressure Switch	Whirlpool W10268911

TIMERS



570-77220-1-AM



CDT-401

- Utilize molded cams and rotating switches to precisely control all appliance functions, ranging from washer spin cycles to multiple dryer circuits.
- Driven by long-life synchronous motors, these parts are engineered to replace faulty units and restore appliances to original factory-standard performance.

[Learn More](#) »

Part No.	Description	Replaces
168-076-AM	Washer Timer	Electrolux 131437500
570-75570-1-AM	Washer Timer	Whirlpool WP8541110
570-77220-1-AM	Washer Timer	Whirlpool W10187167
570-77550-1-AM	Washer Timer	Whirlpool W10243947
571-75800-1-AM	Washer Timer	Whirlpool WP8557393
571-76310-1-AM	Washer Timer	Whirlpool 8577356
571-76610-1-AM	Washer Timer	Whirlpool W10111389
571-77090-1-AM	Washer Timer	Whirlpool W10175557
571-77100-1-AM	Washer Timer	Whirlpool W10177827
571-77230-1-AM	Washer Timer	Whirlpool W10199989
162-528	Dryer Timer	GE WE4X795
162-701-1-AM	Dryer Timer	Whirlpool W10185969
162-703-1-AM	Dryer Timer	Whirlpool W10185971
162-708-1-AM	Dryer Timer	Whirlpool W10185975
162-714-1-AM	Dryer Timer	Whirlpool W10642934
162-716-1-AM	Dryer Timer	Whirlpool W10685024

Part No.	Description	Replaces
CDT-401	Dryer Timer	Whirlpool W10185981
CDT-402	Dryer Timer	Whirlpool W10185982
CDT-412	Dryer Timer	Whirlpool W10186032
CDT-417	Dryer Timer	Whirlpool W10436302
CDT-418	Dryer Timer	Whirlpool W10436303
CDT-419	Dryer Timer	Whirlpool W10634750
CDT-602	Dryer Timer	Whirlpool W10185992
CDT-604	Dryer Timer	Whirlpool W10642928
CDT-702	Dryer Timer	Whirlpool W10185970
CDT-704	Dryer Timer	Whirlpool W10185972
CDT-705	Dryer Timer	Whirlpool W10185997
CDT-709	Dryer Timer	Whirlpool W10185976
CDT-719	Dryer Timer	Whirlpool W10745654
CDT-720	Dryer Timer	Whirlpool W10745655
CDT-806	Dryer Timer	Whirlpool W10185988
CDT-820	Dryer Timer	Whirlpool W10436308

WATER VALVES



CW-001



K-78368-AM

- Features a unique diaphragm design and encapsulated coils to prevent contamination and resist moisture.
- Many models include a corrosion-resistant guide tube that ensures quieter operation and increased durability.

[Learn More](#) »

Part No.	Description	Replaces
CW-001	Washer Water Valve	Whirlpool 13X86, 13X10024, 75D2937P001
CW-1220	Washer Water Valve	Electrolux 134371220
CW-151	Washer Water Valve	Universal Part
CW-333	Washer Water Valve	Whirlpool 22004333
CW-346	Washer Water Valve	Whirlpool 3979346
CW-347	Washer Water Valve	Whirlpool 222700, 3979347
CW-349	Washer Water Valve	Whirlpool W10337349
CW-400	Washer Water Valve	Electrolux 134211400
CW-402	Washer Water Valve	Speed Queen 201402
CW-468	Washer Water Valve	Speed Queen 201468
CW-471	Washer Water Valve	Whirlpool 461970229471, 8182862
CW-551	Washer Water Valve	Whirlpool 461970201551, 8181694
CW-600	Washer Water Valve	Electrolux 134890600
CW-751	Washer Water Valve	Whirlpool 8540751
CW-932	Washer Water Valve	Whirlpool 21001932, 35-6693

Part No.	Description	Replaces
K-65859-AM	Washer Water Valve	Whirlpool 285660
K-66937-AM	Washer Water Valve	Whirlpool 358276
K-74767	Washer Water Valve	Whirlpool 22002882
K-75821-05	Washer Water Valve	Electrolux 134866600
K-75915-AM	Washer Water Valve	GE WH13X10024, 175D2937P001
K-76341	Washer Water Valve	Whirlpool 8578341
K-77052-AM	Washer Water Valve	Whirlpool W10175893
K-77573-1-AM	Washer Water Valve	Whirlpool 134959340
K-77629	Washer Water Valve	Electrolux 137465100
K-77668-AM	Washer Water Valve	Whirlpool W10326913
K-77712-AM	Washer Water Valve	Electrolux 137353500
K-78005-AM	Washer Water Valve	Whirlpool W10342320
K-78043-AM	Washer Water Valve	Whirlpool W10505663
K-78279-AM	Washer Water Valve	Mabe 189D5366P003
K-78280-AM	Washer Water Valve	Mabe 189D5366P004

WATER VALVES

Part No.	Description	Replaces
K-78354-2-AM	Washer Water Valve	GE 290D1232G003
K-78567-AM	Washer Water Valve	Whirlpool W10717709
K-78633-1	Washer Water Valve	Whirlpool W10465981
K-78849-AM	Washer Water Valve	Mabe 189D5366P006
K-78863-1	Washer Water Valve	Mabe 290D1316G007
K-78863-2	Washer Water Valve	GE 290D1316G008
K-78990	Washer Water Valve	Electrolux A07579601
VVV1808-01UC	Washer Water Valve	Whirlpool 320300
VVV1808-02UC	Washer Water Valve	Whirlpool 320301
VVV1810-01UC	Single Valve Consul, 110V-127V, 50/60Hz	Whirlpool 326004752
VVV1810-02UC	Single Valve Consul, 220V-240V, 50/60Hz	Whirlpool 326004753
VVV1912-02UC	Washer Water Valve	Electrolux 6428115

Part No.	Description	Replaces
VVV2803-02UC	Washer Water Valve	Electrolux 64287434
VVV2806-01UC	Washer Water Valve	Electrolux 64287543
VVV2806-02UC	Washer Water Valve	Electrolux 64287449
VVV2807-01UC	Washer Water Valve	Whirlpool 326007073
VVV2807-02UC	Washer Water Valve	Whirlpool 326007924
VVV3901-01UC	Triple Valve, 110-127V, 50/60 Hz	Whirlpool 4257790
VVV3901-02UC	Triple Valve, 220-240V, 50/60 Hz	Whirlpool 4258665
VVV3902-01UC	Triple Valve, 110V-127V, 50/60Hz, LTR15 LTC15 LTA15	Electrolux 64500221
VVV3902-02UC	Triple Valve, 220V-240V, 50/60Hz, LTR15 LTC15 LTA15	Electrolux 64500222
K-78368-AM	Dryer Water Valve	Whirlpool W10562805
K-78372-AM	Dryer Water Valve	Whirlpool W10595507