


Warning: Read installation instructions carefully before installing the Vibration Absorber Hose.

Install the Vibration Absorber Hose at the right angle to the direction of the vibration. If the vibration is in two directions, use two Vibration Absorber Hoses: one for vertical vibration and one for horizontal vibration. The Vibration Absorber should be installed as close to the compressor as possible.



Anchor the refrigerant line to a solid structure at the end farthest away from the compressor beyond the last Vibration Absorber Hose.

Do not use the Vibration Absorber Hose to correct for offset of misalignment.

